



Product Specification Report

Rev. 1.1

A special anti-bacterial agent in tablet-form, which stops the spread and growth of bacteria

ZEP SPLIT

Sanitizing tablets for drain pans of AC units

FEATURES:

Biological control	Acts efficiently against growth of bacteria and fungi, which create sediments and sludge. Especially intended for controlling <i>Legionella Pneumophila</i> bacterium, for perfect disinfection of installations. Acts against slime-forming bacteria and ensures free flow of water.
Long lasting action	ZEP SPLIT keeps drain pans and lines clean and sanitized for 2-3 months
Eliminates clogging	Eliminates clogging of waste condensate pipes and tanks that is caused by slime forming bacteria, rust, water scale, algae, slime and sedimentation
Protects	Protects walls, ceilings and floors against excessive condensate
Safe	Compatible with commonly used materials in air conditioning systems

APPLICATIONS:

ZEP SPLIT is designed specifically for drain pans of AC units. Ideal for hotels, motels, hospitals, offices, schools etc.

ACTIVE INGREDIENTS:

- ✓ Benzalkonium chloride

INSTRUCTIONS FOR USE:

1. Separate a single tablet from the blister pack using scissors
2. Press firmly on the tablet to allow contact between the product and the spongy part below
3. Place the tablet close to the drain hole, spongy part facing downwards

Use 2-4 tablets depending on the size of the air con unit.

PRECAUTIONS FOR USE:

Keep away from sources of heat and sunlight. For more information, refer to the MSDS

SANITIZING ACTIVITY:

The product has been tested and proven effective, following the UNI EN 1040:2005 standard procedure, against:

- ✓ *Pseudomonas aeruginosa*
- ✓ *Staphylococcus aureus*
- ✓ *Legionella pneumophila*

COMPATIBILITY:

Plastic and all metals including aluminium.

SPECIFICATIONS:

FormSolid (tablets)
 ColourWhite
 OdourCharacteristic but mild
 Density at 20°C0,91 g/cm³
 Solubility in waterPartially soluble

PACKAGING:

Each blister pack contains 10 tablets. Each package holds 10 blisters for a total of 100 tablets. Dimensions: 4,5 cm (length) x 3,0 cm (width) x 0,6 cm (height).

All information in this document is based on our practical experience and/or laboratory tests. Due to the multiplicity of conditions for usage and variable human factors, we recommend that you always test our products for suitability prior to use. At any time, this version of the product specification report may have been revised based on legislation, availability of the individual ingredients or newly acquired information. The current approved version is available upon request.

IT
Zep Italia s.r.l.
 T • 800 016 918
 Numero Verde Tecnico
 800-579185
 a tecnico@zep.europa.com
 www.zep.it

UK
Zep UK Ltd.
 T • 0151 422 1000
 F • 0151 422 1011
 info@zep.co.uk
 www.zep.co.uk

BE
Zep Industries BV
 T • 02 347 01 17
 F • 02 347 13 95
 sales@zep.be
 www.zepindustries.be

NL
Zep Industries BV
 T • 0164 250100
 F • 0164 266710
 info@zepbenelux.com
 www.zepindustries.nl

DE
Zep Industries BV
 T • 0521 174158
 F • 0521 5217114
 sales@zepbenelux.com
 www.zepindustries.de